
EHS EXTENSION WIRE KIT INSTALLATION

DB68-13012A-00

■ **Model: MVW-EE300**


Parts

Part Name	Display Cover	Extension Wire	Installation Manual
Quantity	1 EA	1 EA (30m)	1 EA
Shape			


Installation

* For detail information, refer the product installation manual.


1. Remove the AI HOME from product.




2. Remove the Wire from product and AI Home.



Insert the flat-head screwdriver into a square grooves at the bottom of the AI Home and slightly turn to lift the front from the rear cover




3. Installation of AI Home to the wall.




Before fixing the rear cover, secure at least 10 mm space of left, right, upper side, and 50 mm for bottom side

4. Connect extension wire(30m) to main board & AI Home.




Connect the optional 30m wire to the CN301 port of main board and AI Home

5. Reassemble the Product and AI HOME.



Fix the front cover decoration panel to the front panel



Align the controller with the upper groove first, and then insert it by turning it downwards as shown in the figure.
After assemble, check that no wires are stuck in the gap between the back and front cover